



IAB108V10-4U Extender Installation Manual

Included in this package

(2) IAB104 Main Bracket ◆



(2) 5" Extension "L" Bracket. ❖



This document describes how to install IAB108 adjustable depth extender into a rack or cabinet.

Installation Steps

Step 1. Use included #10-32 or #12-24 rack screws to attach 5" Extension "L" bracket to the rack or cabinet as shown in the illustration Figure #1. For heavier load, install additional rack screws to ensure proper weight support.

Step 2. Use a Phillips (cross-head) screwdriver and a plier to attach the IAB104 Bracket to the 5" "L" Bracket with the included #10-32 screw and #10-32 Hex Nuts. Adjust the IAB104 Bracket forward or back to the required distance. Attach (4) #10-32 screw into OB holes as shown in the illustration Figure #2 with Hex Nuts secure on other side as shown in Figure 3

Step 3. Attach empty square holes on IAB104 Bracket with included #10-32 cage nuts. Adjust cage nuts to desire position for your 19" rackmount equipment.

Step 4. Repeat Step 1 to 3 for left side of the cabinet.

(20) #10-32 x 5/8 Rack Screws



(4) #12-24 x 5/8 Rack Screws



(8) #10-32 Hex Nuts



(8) #10-32 Cage Nuts

